





# Helpful hints for cleaning Vitratec Bricks

The smooth, rich colours of Austral Bricks popular slurry bricks are partly thanks to a manufacturing process that dates back hundreds of years.

We call it Vitratec, which is our unique technology for applying a permanent coating to the surface of the brick as it is being extruded and prior to firing.

Once fired at temperatures in excess of 1000°C, the Vitratec coating is permanently bonded to the brick body.

It's a technology that is similar to the glazes applied to other ceramics such wall tiles. As we know, these ceramic glazes are remarkably durable.

However nothing is indestructible, especially with the high-pressure cleaners available today. Care needs to be taken when cleaning all brickwork, and Vitratec coated bricks are no exception.



BEFORE HIGH PRESSURE CLEANING Urban One Chocolate



CORRECT HIGH PRESSURE CLEANING  $<7000 \text{ kPa}, >15^{\circ}, >500 \text{ mm}$ 



AFTER HIGH PRESSURE CLEANING Urban One Chocolate

#### **CLEAN AS YOU GO**

Cleaning as you go is the best method for ensuring clean brickwork. The cleaner the bricklayer leaves the wall, the better the result. Mortar smears are best cleaned when fresh.

### **HIGH PRESSURE WATER**

If used incorrectly, can be a real problem for ANY brick and will damage mortar joints. Keep the pressure low – less than 7000 kPa or 1000 psi – and apply with a wide fan nozzle, not less than 15 degrees, at about 500 mm.

Test a small area first and keep the gun moving constantly. Turbo heads are not recommended as there is a high potential for damage to bricks and mortar.

All brickwork should be treated with respect when cleaning and Vitratec bricks such as our Urban One series are no exception.

## **ACID CLEANING**

Acid Cleaning is highly effective at removing mortar smears. (Hydrochloric acid dissolves the cement component.) Too much acid may cause the brick face to 'burn'.

## IN SUMMARY

- > Vitratec bricks are as durable as conventional bricks
- Clean as you go is the way to go
- Take care when acid cleaning ANY bricks
- Throttle back when pressure cleaning ALL brickwork: not more than 7000 kPa, no narrower than 15 degrees, no closer than 500 mm

NB: Urban One bricks are best laid with a full mortar joint or an ironed joint.

#### WANT TO KNOW MORE ABOUT BRICK CLEANING AND STAIN REMOVAL?

Download Brick Manual 3, Brick cleaning and maintenance from the Austral Bricks website www.australbricks.com.au (Look in Information Sheets and Manuals under Technical Resources).

Cleaning Clay Masonry, available from Think Brick Australia www.thinkbrick.com.au (Click on Reference Library).

Follow brickworksbuildingproducts on











13 BRICK (13 2742) | www.australbricks.com.au















BOWRAL BRICKS



**INEX** > BOARDS

