

## PAINTING SCHEDULE

Produced by: Taubmans Paints (PPG PTY LTD)

Project: Brickworks Pronto Panels



## ARMAWALL EXTERIOR TEXTURE COATING SYSTEM.

### ARMAWALL POLYMER RENDER (PAINTED)

#### SURFACE PREPARATION

##### SUBSTRATE: BRICKWORKS PRONTO PANEL

Armawall Surface Preparation Products are designed to perform at their optimum when used as part of an Armawall Texture Coating System.

The surface should be clean, dry and free from all dirt, dust, grease, oil, mould and any other surface contamination that may affect adhesion. Ensure all Pronto Panels are securely fixed and in accordance with manufacturer's specifications.

Cut Armawall Mesh to required joint length. Joints are flush finished to the sheet face with Armawall Coarse Patch with the addition of 20% grey cement powder into the compound prior to application.

Apply a second (2nd) coat of Armawall Coarse Patch and fully encapsulate the Armawall Mesh avoiding excess material build up. Any excess material build up of compound can be removed by using a damp sponge and lightly wiping over the surface. Allow to dry for 24 hours minimum.

The moisture content of the substrate must be below 15% wood moisture equivalent (WME) prior to & during the application of the specified Armawall system.

*Special note: Surface preparation is the responsibility of the Applicator, Builder, Renovator or Main Contractor.*

#### Substrate: New Pronto Panels External Walls – 10 year Warranty

##### External Walls – 10 year Warranty

1 <sup>st</sup>	Armawall Polymer Render – applied using trowel
2 <sup>nd</sup>	Armawall Polymer Render – applied using trowel & plastic float
3 <sup>rd</sup>	Armawall Armashield – applied using a 15mm nap roller
4 <sup>th</sup>	Armawall Armashield – applied using a 15mm nap roller

#### Additional Comments

Apply first coat of Armawall Polymer Render as a tight skim coat (approx. 2mm thickness)