

## Ridgi Fence Bracket Installation Guide

**You will need:** RIDGI 3mm fence brackets, 10mm nyloc bolt, cordless drill, 8mm allen key and socket to suit, marking pen

1. Line up fence bracket on post, mark on the post where you require holes
2. Drill 2, 3mm holes through the posts then over that drill a 10mm hole. This allows easier drilling
3. Line up fence bracket on holes, insert bolts and tighten the nuts to secure to the post
4. Insert the top 2 rows of the concrete sleepers

**Helpful tip:** When installing the steel posts ensure you allow an extra 15-30mm spacing to have enough clearance for the bolts.

**Engineer note:** Depending on your soil conditions you may need to allow extra pier depth when putting a fence on top. As a guide, we recommend having an extra 400mm deeper pier when putting a standard 1.8m fence on top. If you are unsure consult an engineer or call us on 07 3348 1200.